








# ASSEMBLY INSTRUCTION

## NC\*MX | Male XLR Cable Connector



**A** Slide the boot onto the cable.

**B** Prepare cable as shown.  
Cable O.D. 3.5 - 8.0 mm [0.14 - 0.32"]  
Wiresize max. 2.5 mm<sup>2</sup> / AWG 14

**C** Insert wires into the terminals and solder them.

**D** Put chuck onto the cable.


**Attention:**  
Pay attention to the exact position as shown in the picture.

**E** Slide insert and chuck together into the housing.

**Attention:**  
Pay attention to the position of the key.

**F** Finish the installation by turning the bushing onto the connector.

### SCOPE OF DELIVERY



XLR Connectors:  
Find more details on  
[www.neutrik.com](http://www.neutrik.com)



\*: 3 - 7 contacts

Neutrik AG LI T: +423 / 237 24 24 F: +423/232 53 93  
Neutrik USA Inc. USA T: +1 704 / 972 3050 F: +1 704/438 9202  
Neutrik (UK) Ltd. UK T: +44 1983 / 811 441 F: +44 1983/811 439  
Neutrik Vertriebs GmbH DE/NL/AT/DK T: +49 8131 / 280 890 F: +49 8131/280 830

Neutrik France FR T: +33 1/4131 6750 F: +33 1/4131 0511  
Neutrik Tokyo Ltd. JP T: +81 3/3663 4733 F: +81 3/3663 4796  
Neutrik Hong Kong Ltd. HK T: +852/2687 6055 F: +852/2687 6052  
Neutrik India Pvt. Ltd. IND T: +91/982 05 43 424 F: +91/22 26163 540

Draft. Nr.: BDA 610 | Update: 2020-06-07 | Data subject to change without prior notice. © 2020 NEUTRIK®. NEUTRIK® are registered trademark of Neutrik AG. ALL RIGHTS RESERVED.

[www.neutrik.com](http://www.neutrik.com)

**NEUTRIK**